





ELEC_RA	A4	A4	B4	B4	ELEC_RA
ELEC_RA	A9	A9	B9	B9	ELEC_RA
	A2	SSTXP1	SSRX1	B11	
	A3	SSTXN1	SSRXN1	B10	
ELEC_RL	A5	CC1	SBU2	B8	
	A6	DP1	DN2	B7	ELEC_LL
ELEC_LL	A7	DN1	DP2	B6	
	A8	SBU1	CC2	B5	ELEC_RL
	A10	SSRXN2	SSTXN2	B3	
	A11	SSRX2	SSTX2	B2	
	G1	SHIELD	B1	B1	ELEC_LA
	G2	SHIELD	B12	B12	ELEC_LA
	G3	SHIELD	A1	A1	ELEC_LA
	G4	SHIELD	A12	A12	ELEC_LA

AGND

OCKET

X1

USB4080-03-A TYPEC